

SOKKIA

S-10

Mobile Field Controller



- **Windows Mobile® 6.5**
- **624MHz Intel X-Scale Processor and Graphics Accelerator**
- **Integrated Bluetooth®, Wi-Fi, and Cellular Modem**
- **Integrated 5 Megapixel Camera**
- **VGA Color Display, Sunlight-readable Transflective Touch Screen**
- **Waterproof IP65**

S-10

Mobile Field Controller

SPECIFICATIONS



System	
CPU	624MHz Intel X-Scale processor with built-in Graphics Accelerator
OS	Microsoft Windows Mobile® 6.5
Memory	256MB NAND Flash MicroSD Card Slot
Display	Sunlight-readable 3.7 in. VGA (480 x 640) transfective touch screen
Communications	Wireless LAN 802.11 b/g Bluetooth® USB Type Mini-B
Integrated Sensors	
GPS Type	12 channel SIRFstar III chipset
GPS Horizontal Accuracy	2-5 m
Built-in Camera	5 MP, Autofocus Camera
Environmental	
Water Protection	IP65
Operating Temperature	-4°F to 140°F (-20°C to 60°C)
Storage Temperature	-22°F to 158°F (-30°C to 70°C)
Drop Test	Drop 3.3' (1 m)
Physical Characteristics	
Dimensions (W x H x L)	3.7" x 6.3" x 1.2" (94 x 160 x 30.5 mm)
Weight with Battery	9.6 oz (272 g)
Battery	3000 mAh Li-Ion battery
Operating Time	Up to 10 hours of operation

An entry-level field controller that has high performance in a compact design delivering results with the MAGNET® software family.

Rugged

The S-10 is a handheld controller that is waterproof (IP65) with an integrated cell modem and Bluetooth® connectivity allowing the user to easily connect to GNSS receivers cable free for network correction or MAGNET Relay.

Long Life Battery

The 3000 mAh Li-Ion battery provides up to 10 hours to your extended working day.

Easy, Intuitive Operation

Windows Mobile® 6.5 operating system and the 3.7" sunlight readable display with MAGNET Field is simple to operate.

Integrated Sensors

The 12 channel GPS provides a 2-5 meter solution for locations in the field to tag Geo locations for pictures recorded with the 5 MP camera.

Kit Components



Standard Configuration

- S-10 Controller
- Handstrap
- Stylus
- USB cable and Charger
- Quick Start Guide
- Battery

Optional Accessories

- Pole Bracket

SOKKIA

SOKKIA CORPORATION

16900 W. 118th Terrace Olathe, KS 66061
Phone (800) 4-SOKKIA Fax: (913) 492-0188
www.sokkia.com

Specifications subject to change without notice
©2014 Sokkia Corporation All rights reserved.
SOK-1027 Rev A 10/14

Your local Authorized Dealer is: